

#	COMPONENT	QTY
1	TOP COVER	1
2	SCREW	2
3	PLATE	1
4	CONTROL GEAR - PSU	1
5	SCREW	2
6	LIGHT SOURCE - LED MODULE	1
7	SCREW	1
8	DIFFUSER	1
9	SCREW	2
10	HEAD	1
11	PROFILE	1
12	SCREW	4
13	SCREW	1
14	COVER	1
15	SCREW	1
16	TERMINAL BLOCK	1
17	BASE	1
18	SCREW	4

Warnings
Always make sure the luminaire is detached from the mains socket
Always make sure the DC cable is detached from the power supply
Staring at the operating light source may cause eye injury

#	Disassemble/dismantle steps	Tools needed		
а	REMOVE THE TOP COVER (1)	FLAT HEAD SCREW DRIVER		
b	REMOVE BASE (17) FROM THE PROFILE (11) BY UNSCREWING THE SCREWS (18)	CROSS HEAD SCREW DRIVER		
С	REMOVE COVER (14) BY UNSCREWING THE SCREW (13)	CROSS HEAD SCREW DRIVER		
d	REMOVE WIRES OF THE CONTROL GEAR - PSU (4) FROM THE TERMINAL BLOCK (16)	FLAT HEAD SCREW DRIVER		
е	REMOVE DIFFUSER (8) BY UNSCREWING THE SCREWS (9)	CROSS HEAD SCREW DRIVER		
f	REMOVE LIGHT SOURCE - LED MODULE (6) FROM THE PLATE (3) BY UNSCREWING THE SCREW (7)	CROSS HEAD SCREW DRIVER		
g	REMOVE WIRES OF THE CONTROL GEAR - PSU (4) FROM THE LIGHT SOURCE - LED MODULE (6)	SOLDER IRON		
h	REMOVE THE CONTROL GEAR - PSU (4) BY UNSCREWING THE SCREWS (5)	CROSS HEAD SCREW DRIVER		

SKU	Color	Country
915005378101	BLACK	EU
915005378201	BLACK	EU

1	STA	TUS	DESCRIPTION				DESIGN ID	DESIGN ID	
				edestal black 1x8W 230V					
			Parterre po	ost black 1x8W 230V			DOC 12NC	DOC 12NC	
	2021-04-12								
NAME WH		LOCAL PART ID		SH. 1	SH.		A3-P		
		CHECKED		DATE			CONFIDENTIAL, PROPERTY OF: © 2020 Signify Holdin		ding