

#	COMPONENT	QTY
1	COVER	1
2	DIFFUSER	1
3	SCREW	4
4	LIGHT SOURCE - LED MODULE	1
5	SCREW	2
6	CONTROL GEAR - PSU	1
7	SCREW	2
8	CLAMPER	1
ഗ	PLATE	1
10	SCREW	4
11	TERMINAL BLOCK	1
12	BASE	1
13	SCREW	2

Warnings
Always make sure the luminaire is detached from the mains socket
Always make sure the DC cable is detached from the power supply
Staring at the operating light source may cause eye injury

#	Disassemble/dismantle steps	Tools needed
а	REMOVE BASE (12) BY UNSCREWING THE SCREWS (13)	CROSS HEAD SCREW DRIVER
b	UNSCREW WIRES OF THE CONTROL GEAR - PSU (6) FROM THE TERMINAL BLOCK (11)	FLAT HEAD SCREW DRIVER
С	REMOVE COVER (1) AND DIFFUSER (2) BY UNSCREWING THE SCREWS (10)	CROSS HEAD SCREW DRIVER
d	REMOVE LIGHT SOURCE - LED MODULE (4) BY UNSCREWING THE SCREWS (3)	CROSS HEAD SCREW DRIVER
е	REMOVE WIRES OF THE CONTROL GEAR - PSU (6) FROM THE LIGHT SOURCE - LED MODULE (4)	SOLDER IRON
f	REMOVE THE CLAMPER (8) BY UNSCREWING THE SCREWS (7)	CROSS HEAD SCREW DRIVER
g	REMOVE THE CONTROL GEAR - PSU (6) BY UNSCREWING THE SCREWS (5)	CROSS HEAD SCREW DRIVER

SKU	Color	Country
915005554301	BLACK	EU

S ⁻	TATUS	DESCRIPTION				DESIGN ID		
		Actea wall	ea wall lantern black 1x12W 176V			DOC 12NC		
2021-04-12								
NAME	JZ	·	LOCAL PART ID	SH. 1		SH.		A3-P
CHECKED			DATE		CONFIDENTIAL, PROPERTY OF: © 2020 Signify Holding			